

Operating Instructions for Summit Chairs Scope Range, Model SCT132.

All adjustments should be made whilst you are seated.

1. The overall height of the chair can be adjusted by lifting the lever located below the middle of the seat on the right-hand side. Lift your weight off the chair allowing it to rise and release the lever at the required height. To lower the chairs simply lift this lever and release at the required height.
2. The synchronised recline of the seat and back can be adjusted by twisting the rotary control located below the seat on the left-hand side. This control can be slid outwards for easier access. The seat and back can be unlocked by twisting the control anti clockwise or locked at the required angle by twisting the control clockwise. If the control is left in the unlocked position the seat and back will follow your movements in free float mode. Please be aware that there is a safety feature that requires you to lean gently into the back of the chair before the lock will release.
3. The tension of the synchronised recline can be adjusted by twisting the rotary control located under the front of the seat on the right-hand side. This tension control slides out for easy access.
4. If the chair is fitted with an optional seat slider the seat depth can be adjusted by lifting the lever located below the middle of the seat on the left-hand side. Slide the seat forwards and backwards until the required position is achieved and release the lever to lock the seat in place.
5. If the chair is fitted an inflatable lumbar support this can be adjusted by using the hand bulb that hangs under the left-hand side of the seat. Squeeze the bulb to inflate the support and press the button on the bulb to deflate it.
6. The back height can be adjusted by lifting the back up a step at a time until the correct positioning of the lumbar support is achieved. When the back reaches the top of its travel it will drop back to the start position.
7. The height adjustable arms have a lever located under the inside edge of the arm pad. Press this in and lift the arm to the desired position.